



- Professional termite treatment based on pure Neem Oil approved by ECOCERT
- Non-toxic ready-to-use emulsion
- Protects wood, bamboo, houses and gardens

\*\*\*\*\*

## WOOD PROFESSIONAL PREPARATION & TREATMENT PROCESS

*For small Industry use. Please contact us for bigger industrial purposes*

\*\*\*\*\*

Freemite200+ has been designed not only to be efficient but also to provide a convenient and simple process for professional use.

For optimal penetration and protection, here are our step-by-step recommendations in using Freemite200+.

- 1 Prepare the wood sections and clean them
  - To clear the surface from impurity, dust, etc.
- 2 Immerse fully the wood sections in a pool of Freemite200+ diluted with clean and non-chlorinated water. Leave them to soak for 24 to 72 hours (depending on the hardness and section of the wood)
  - To treat them against termites
- 3 Dry the wood sections shortly above the pool
  - To allow the treatment inside the wood to drop back in the pool. You can then add another batch of wood in the pool



- 4 Dry the wood 1 day under the sun
- 5 Store the wood in a dry, ventilated horizontal place
  - The treated wood is ready for production

\*\*\*\*\*

## IMPORTANT TIPS TO ENSURE OPTIMUM EFFICIENCY OF A FREEMITE200+ BATH

- ❖ Each bath will be efficient up to 30 to 50 days depending on the local environmental conditions (especially dust), your own care, the cleanness of the water and the wood
- ❖ Cover the pool when the wood sections are soaking in order to avoid dust coming in
- ❖ Clean the bath with a net skimmer every time you take out the wood section from the pool

These tips should avoid particles and bacteria to develop in the bath. The longer the bath is used, the more it will bring down the cost of the treatment per bamboo.

If the bath smells it implies there are too many bacteria. In case of heavy smell, prepare a new batch of diluted FREEMITE200+ and use the old one as a fertilizer for your fields, your garden or to treat the foundations of your constructions against subterranean termites, powder post beetles and woodworms.

PESTHAMA IS A BRAND OF PT LESTARI SEMESTA BALI - NPWP: 93.911.950.9-907.000  
KANTOR / OFFICE: JL. PADAT KARYA 9 - DESA BELEGA - GIANYAR - BALI 80581 - INDONESIA  
P: +62 (0) 811 3999 120 - E: [WELCOME@PESTHAMA.COM](mailto:WELCOME@PESTHAMA.COM) - W: [WWW.PESTHAMA.COM](http://WWW.PESTHAMA.COM)



- Professional termite treatment based on pure Neem Oil approved by ECOCERT
- Non-toxic ready-to-use emulsion
- Protects wood, bamboo, houses and gardens

\*\*\*\*\*

## FRESHLY CUT PROFESSIONAL BAMBOO PREPARATION & TREATMENT PROCESS

*For small Industry use. Please contact us for bigger industrial purposes*

\*\*\*\*\*

Freemite200+ has been designed not only to be efficient but also to provide a convenient and simple process for professional use.

For optimal penetration and protection, here are our step-by-step recommendations in using Freemite200+.

1. Clean the exterior knots, leaves and branches with a special knife. Wash the bamboos with clean water and a light abrasive sponge.
  - To clear the surface from impurity, dust, etc.
2. Let the bamboos dry horizontally or vertically under the sun for 10 to 20 days (turning them over every 2 to 3 days) or dry them in an oven until they reach 16% hygrometry.
  - The bamboos should only be treated when they are at least 60% dry for optimal penetration.
3. Make a hole in the inside knots of the bamboos using a long iron stick or a drill with a spinning head.
  - To allow the treatment to be absorbed from inside.
4. Allow the bamboos to soak fully in a pool filled with clear and non-chlorinated water for 3 days.
  - To release some of the starch contained in the bamboos.
5. Immerse fully the bamboos in a pool of Freemite200+ diluted with clean and non-chlorinated water. Leave them to soak for 12 to 72 hours (depending on the species).
  - To treat them efficiently against termites.



6. Dry the bamboos shortly above the pool.
  - To allow the treatment inside the bamboos to drop back in the pool. You can then add another batch of bamboos in the pool.
7. Store the bamboos in a dry and ventilated place, horizontally or vertically.
  - The treated bamboos are ready for production.

\*\*\*\*\*

### IMPORTANT TIPS TO ENSURE OPTIMUM EFFICIENCY OF A FREEMITE200+ BATH

- ❖ Each bath will be efficient up to 30 to 50 days depending on the local environmental conditions (especially dust), your own care, the cleanness of the water and the bamboos
- ❖ Cover the pool when the bamboos are soaking in order to avoid dust coming in
- ❖ Clean the bath with a net skimmer every time you take out the bamboos from the pool

These tips should avoid particles and bacteria to develop in the bath. The longer the bath is used, the more it will bring down the cost of the treatment per bamboo.

If the bath smells it implies there are too many bacteria. In case of heavy smell, prepare a new batch of diluted FREEMITE200+ and use the old one as a fertilizer for your fields, your garden or to treat the foundations of your constructions against subterranean termites, powder post beetles and woodworms.